



# Electronic Dosing Pump

# Aarbee Aqua



**CAPACITY CHART**

MODEL	MAX WORKING PRESSURE (Kg/cm <sup>2</sup> )	MAX DISCHARGE (Litre)	DRIVE
CD 04 05	4	5	Solenoid
	1	10	Solenoid




**CAPACITY CHART**

MODEL	MAX WORKING PRESSURE (Kg/cm <sup>2</sup> )	MAX DISCHARGE (Litre)	DRIVE
KA 01 12	1	12	Solenoid
KA 04 06	4	6	Solenoid
KA 05 05	5	5	Solenoid
KA 10 02	10	2	Solenoid
KA 12 01	12	1	Solenoid




**CAPACITY CHART**

MODEL	MAX WORKING PRESSURE (Kg/cm <sup>2</sup> )	MAX DISCHARGE (Litre)	DRIVE
KB 03 16	3	16	Solenoid
KB 04 12	4	12	Solenoid
KB 06 10	6	10	Solenoid
KB 10 06	10	6	Solenoid



**CAPACITY CHART**



MODEL	MAX WORKING PRESSURE (Kg/cm <sup>2</sup> )	MAX DISCHARGE (Litre)	DRIVE
KC 01 100	1	100	Solenoid
KC 02 75	2	75	Solenoid
KC 04 30	4	30	Solenoid
KC 06 15	6	15	Solenoid
KC 10 10	10	10	Solenoid
KC 15 05	15	5	Solenoid



# Mechanical Dosing Pump

CAPACITY CHART

MODEL	MAX WORKING PRESSURE (Kg/cm <sup>2</sup> )	MAX DISCHARGE (Litre)	DRIVE
KM 03 120	3	120	Motor
KM 05 35	5	35	Motor
KM 05 100	5	100	Motor
KM 05 200	5	200	Motor
KM 08 50	8	50	Motor
KM 10 30	10	30	Motor



CAPACITY CHART

MODEL	MAX WORKING PRESSURE (Kg/cm <sup>2</sup> )	MAX DISCHARGE (Litre)	DRIVE
KH 01 1200	1	1200	Motor
KH 03 1000	3	1000	Motor
KH 05 500	5	500	Motor
KH 08 400	8	400	Motor
KH 10 300	10	300	Motor

**Mumbai :**

148, Naman Plaza, Behind Shopper's Stop,  
S.V. Road, Kandivali(W), Mumbai 400067

Maharashtra.

Tel. : 022 28655050, Fax : 28654949

**Vasai :**

102, Om Kiram Apt., Janak Puri Complex,  
Opp. MSEB Power House, Navghar,  
Vasai Road, Dist. Thane - 401 210.

Tel. : 0250 2393935

**Chhattisgarh :**

Plot No. MIG-63, Kabir Nagar,  
Behind Housing Board Office,  
Tatibandh, Raipur - 492 002.

Telefax : 0771 2325252

**West Africa :**

Block No. 2, 1st Floor,  
Daimond Bldg., Pati Cherry,  
Kollum, Conakry (West Africa)

Tel. : 002 2466201054